



FURNITURE LEISURE INC

1.800.213.2401

www.FurnitureLeisure.com
www.PicnicFurniture.com
www.ParkTables.com

www.PoolFurnitureSupply.com
www.PicnicTableSupplier.com
www.UBrace.com


GNS60



Model : GNS60


HARDWARE IS STAINLESS STEEL
UNLESS OTHERWISE SPECIFIED

- (1) Seat
- (1) Back
- (2) Sideframes



QTY	DESCRIPTION
8	1/4-20 X 1-3/4 WAFER SHCS
2	1/4-20 X 2-1/2 WAFER SHCS Qty 2
4	5/16 x 4" Eyebolt Qty 4
8	5/16 X 3/4 OD FLAT WASHER Qty 8
4	5/16-18 NYLOCK NUT Qty 4
2	.307 X 2-1/2 X 3/4 S-HOOK ZN Qty 2
4	SNAP HOOK 1/4" Qty4
4	5ft ZINC CHAIN QTY 4

TOOLS NEEDED




- 4MM T-HANDLE HEX KEY (INCLUDED)
- PHILLIPS HEAD SCREWDRIVER (SCREW GUN RECOMMENDED)

GNS60 Swing Assembly

Step 1

Finish attaching Arm to Leg using

- (1) 5/16 x 4 Eyebolt
- (1) 5/16 nut
- (2) 5/16 washer




Step 2

Repeat Step 1 for other Leg

Step 3

Attach Sideframes to Seat using


- (4) 1 3/4" bolts



Step 4

Secure Sideframes to Seat using

- (2) 5/16 x 4 Eyebolt
- (2) 5/16 nut
- (4) 5/16 washer




Step 5

Attach Back to Seat using (2) 2 1/2" bolts


Step 6

Attach Side Frames to Back using (2) 1 1/2" bolts




Step 7

Attach Back to seat using
(2) 1 3/4" bolts

**Step 8**

Hang swing



Tip: Seat should measure about 18" from floor