






Furniture Leisure
 Commercial Site Furnishings
 1-800-213-2401 | sales@furnitureleisure.com

FurnitureLeisure.com PoolFurnitureSupply.com
PicnicFurniture.com PicnicTableSupplier.com
ParkTables.com UBrace.com

POLYWOOD

Assembly Instructions



TD202

La Casa Cafe
Bar Arm Chair



20-Year Warranty

To view our full warranty, please visit
polywoodoutdoor.com/warranty

Easily register your product using
one of the methods below:

Text POLYWOOD to 71403

Receive a link to register online

— or —

Register on our website

register.polywoodoutdoor.com

— or —

Send a Picture

Take a photo of the icon below and
text it to 71403 (US only)



Watch & Learn

For assembly videos and more,
visit youtube.com/polywood



Cleaning Tips

Even POLYWOOD gets dirty — here
are some ways to help keep it clean:

For a quick clean:

Simply wipe down with soap and water.

For a deeper clean:

You'll need:

- » ½ bleach and ¾ water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth
and let it sit on the lumber for a few
minutes (this will not affect the color).
Then, loosen any dirt and debris that
may catch in surface grooves with a
soft bristle brush; hose down to rinse.




Share your space

We love to see where our furniture
ends up — snap a pic and share it on
Instagram or Facebook!
#polywood

 **Furniture Leisure**
Commercial Site Furnishings
1-800-213-2401 | sales@furnitureleisure.com

FurnitureLeisure.com PoolFurnitureSupply.com
PicnicFurniture.com PicnicTableSupplier.com
ParkTables.com Ubrace.com

TOOLS





4mm T-handle
hex key (included)




4mm hex, straight,
for drill (included)

PARTS




3" Screw — H.27X3




2.5" Screw — H.27X2.5


1




2



3



4



5

